

Tenant Guide: Bleeding A Radiator

If one of your radiators is not working it may need bleeding which is a very easy issue to fix. This guide will show you how

How To:


1. PREPARE THE RADIATOR

Firstly, you will need a radiator bleeding key. These can be bought from any hardware store for under £2. Next, Check the radiator valve is at the highest setting.




2. INSERT KEY

Insert the key into the end of the radiator as highlighted in the image. Hold a cloth underneath.



3. TURN THE KEY

Slowly and gently turn the radiator key until you hear air coming out.



4. TURN OFF THE AIR

When water appears turn the key in the opposite direction to stop the water and air. The radiator should now be warm.

